


Cabana Panel End Study Carrel

Cubicles

Tools Required:

Phillips screwdriver
6mm wrench



16-1/2"
Z-bracket



M6 x 10mm
Pan Head Screw




#12 x 1"
Pan Head Screw




MOD-EEZ
Stud




M/F MOD-EEZ
Stud



8" x 1-1/2"
FH Screw



1/4-20 x 1-3/4"
JC Connector
Bolt



STEP 1 (Starter Unit) - Attaching end panels to back panels

Screw Mod-eez studs into holes in vertical center line of double end panels or back edge of single end panels.


Slide Mod-eez studs into factory installed Mod-eez clips on either end of back panels.

Cabana-Panel-End-Study-Carrel-instructions-240321




Cabana Panel End Study Carrel

Cubicles



Step 1.2 (Adder Unit):

Mod-eez shoulder screws for double sided units have both male and female parts. One on each side of the center divider panel. Insert female Mod-eez connector bolt into pre-drilled holes in center divider panel. Then insert male Mod-eez shoulder screws into female connector bolts. Place panel (with pre-installed Mod-eez clip) onto the male Mod-eez screw in the center divider panel, as shown. Using a mallet, tap down to secure in place.



STEP 2 - Attach Worksurface Z Brackets


Screw M6 x 10mm pan head screw through "Z" bracket into brass inserts in end/intermediate panels finger tight only for now.

Cabana-Panel-End-Study-Carrel-instructions-240321




Cabana Panel End Study Carrel

Cubicles




STEP 3 - Attach Side Support Panels

Using (4) #8 x 1-1/2" flat head screws, attach side support panels to back bottom section of both vertical panels of the cubicle.



STEP 4 - Attach Worksurface

Position the worksurface onto the "Z" brackets. Make sure the short end of the "Z" bracket sits in the groove. Screw angle brackets to the underside of the worksurface using #12 x 1" screws. Tighten bolts from Step 2.



STEP 5 - Attach Wire Chase Panel to Front of Worksurface

Using 1/4-20 x 1-3/4" JC Bolt, attach the wire chase panel to the front of the work surface and support panels.

Cabana-Panel-End-Study-Carrel-instructions-240321

